CODE FOR CAMERS MODULE

```
void handleJpgLo()
{
   if (!esp32cam:: Camera.changeResolution(loRes)) {
        Serial.println("SET-LO-RES FAIL");
        }
        serveJpg();
}

void handleJpgHi()
{
   if (!esp32cam:: Camera.changeResolution(hiRes)) {
        Serial.println("SET-HI-RES FAIL");
        }
        serveJpg();
}

void handleJpgMid()
{
   if (!esp32cam::Camera.changeResolution(midRes)) {
        Serial.println("SET-MID-RES FAIL");
        }
        serveJpg();
}
```

```
void setup(){
  Serial.begin(115200);
  Serial.println();
  {
   using namespace esp32cam;
   Config cfg;
   cfg.setPins(pins::AiThinker);
   cfg.setResolution(hiRes);
   cfg.setBufferCount(2);
    cfg.setJpeg(80);
   bool ok = Camera.begin(cfg);
   Serial.println(ok ? " CAMERA OK" : " CAMERA FAIL");
 WiFi.persistent(false);
 WiFi.mode(WIFI STA);
 WiFi.begin(WIFI SSID, WIFI PASS);
 while (WiFi.status() != WL CONNECTED) {
   delay(500);
  Serial.print("http://");
  Serial.println(WiFi.localIP());
  Serial.println(" /cam-lo.jpg");
  Serial.println(" /cam-hi.jpg");
  Serial.println(" /cam-mid.jpg");
  server.on("/cam-lo.jpg", handleJpgLo);
  server.on("/cam-hi.jpg", handleJpgHi);
  server.on("/cam-mid.jpg", handleJpgMid);
  server.begin();
```

```
#include <WebServer.h>
#include <WiFi.h>
#include <esp32cam.h>
const char* WIFI SSID = "motorola edge 50 pro 3420";
const char* WIFI PASS = "password";
WebServer server(80);
static auto loRes = esp32cam::Resolution::find(320, 240);
static auto midRes = esp32cam::Resolution::find(350, 530);
static auto hiRes = esp32cam::Resolution::find(800, 600);
void serveJpg()
  auto frame = esp32cam::capture();
  if (frame == nullptr) {
    Serial.println("CAPTURE FAIL");
    server.send(503, "", "");
    return;
  Serial.printf("CAPTURE OK %dx%d %db\n", frame->getWidth(), frame->getHeight(),
                static cast<int>(frame->size()));
  server.setContentLength(frame->size());
  server.send(200, "image/jpeg");
  WiFiClient client = server.client();
  frame->writeTo(client);
```